

The diagram illustrates the Tefal Calor Steam Iron 2500W with the following features and controls:

- Steam Boost:** Indicated by a cloud icon and the text "STEAMBOOST" above the steam soleplate.
- Steam Boost x3:** A feature that multiplies steam output, shown with a "x3" multiplier.
- Lock Release:** A button on the handle to lock the soleplate for ironing.
- Water Tank:** The large reservoir at the back for water, with a "1.7L MAX" mark.
- Water Inlet:** A tap for filling the water tank.
- Anti-calc:** A feature to prevent limescale buildup, indicated by a cloud icon and the text "Anti-calc Press 3s."
- Mode Selection:** Buttons for "Eco", "Normal", and "Max" steam settings.
- Power Button:** A power symbol button.
- Soleplate:** The bottom plate of the iron, shown with a close-up of the steam holes.
- Steam Hose:** The flexible hose that carries steam from the tank to the soleplate.

At the bottom right, the website www.tefal.com and www.calor.fr are listed, along with a download icon.

1.

www.tefal.com  www.calor.fr 



2.


www.tefal.com  www.calor.fr 




3.

www.tefal.com  www.calor.fr

ON



The diagram illustrates the steps to turn on the iron:

1. Pull out the soleplate.
2. Plug the cord into the power outlet.
3. The iron is shown plugged in.
4. Press the power button.
5. The power button is illuminated with a blue starburst.
6. The power button is illuminated with a blue starburst and the word "OK" is visible.

4.



www.tefal.com
www.calor.fr























Eco	Normal	Max
		
		


5. www.tefal.com www.calor.fr





6. **AUTO OFF** www.tefal.com www.calor.fr



7. **ANTI CALC** www.tefal.com www.calor.fr




8. **OFF** www.tefal.com www.calor.fr



9. www.tefal.com www.calor.fr



FR Guide de l'utilisateur	HU Használati útmutató
EN User's guide	SL Navodila za uporabnika
DE Bedienungsanleitung	RU Руководство пользователя
NL Gebruiksaanwijzing	UK Посібник користувача
ES Guía del usuario	HR Upute za uporabu
PT Guia del usuario	RO Ghidul utilizatorului
IT Manuale d'uso	ET Kasutusjuhend
DA Brugsvejledning	LT Naudootojo vadovas
NO Bruksanvisning	LV Lietošanas pamācība
SV Användarhandbok	BG Ръководство на потребителя
FI Käyttöopas	SR Korisničko uputstvo
TR Kullanım kılavuzu	BS Korisnički priručnik
EL Οδηγός χρήσης	FA راهنمای کاربر
PL Instrukcja obsługi	AR دليل المستخدم
CS Návod k použití	TH คู่มือสำหรับผู้ใช้งาน
SK Používateľská príručka	ZH 使用指南



POWER PRO COMPACT 300

FR Pour plus d'informations sur l'utilisation / EN For further usage information / DE Weitere Informationen zur Bedienung / NL Voor meer informatie over het gebruik / ES Para obtener más información sobre su uso / PT Para obter mais informações sobre a utilização / IT Per maggiori informazioni sull'utilizzo / DA Yderligere informationer vedrørende betjening / NO For mer informasjon om bruken / SV För mer information om användningen / FI Lisätietoja käyttöä varten / TR Kullanım hakkında daha fazla bilgi için / EL Για περισσότερες πληροφορίες σχετικά με τη χρήση / PL Więcej informacji na temat korzystania z urządzenia / CS Pro více informací o použití / SK Pre ďalšie informácie o používaní / HU A használatra vonatkozó további információk / SL Več informacij o uporabi / RU Для получения более подробной информации об эксплуатации / UK Для отримання детальної інформації щодо експлуатації / HR Za više informacija o upotrebi / RO Pentru mai multe informații privind utilizarea / ET Täiendava teabe saamiseks kasutamise kohta / LT Daugiau informacijos apie naudojimą / LV Lai iegūtu vairāk informācijas par lietošanu / BG За още информация относно употребата / BS Za više informacija o upotrebi / SR Za više informacija o upotrebi / FA برای اطلاعات بیشتر درباره استفاده / AR للمزيد من المعلومات عن الاستعمال / TH สำหรับข้อมูลเพิ่มเติมเกี่ยวกับการใช้งาน / ZH 更多关于使用的信息: