


What's in the Box


For Camera Installation



Camera




5V/1A USB
Adapter



2m USB-C
Cable



Mounting Bracket



Screw Pack


For HomeBase Setup (Optional)




HomeBase Mini



5V/2A Power
Adapter




2m Power
Cable



Ethernet Cable

Other



Quick Start Guide

Tools You Will Need



Phillips Screwdriver



Power Drill (6 mm)





Hammer

Before Mounting


1. Download the eufy App



2. Add HomeBase Mini (Optional)



3. Add the Camera



If you purchased a kit with HomeBase Mini, keep HomeBase Mini within 3.3 ft (1m) of the camera when pairing.

4. Insert and Remove the microSD Card (Optional)

- ① Unscrew and open the SD card slot cover.
- ② Insert the microSD card with its pins facing **down** for the camera, but **up** for the HomeBase Mini. Press the card into the slot until it clicks into position.
- ③ To remove the microSD card, press it inward until it springs loose, then pull it out from the slot.

Do not insert or remove the microSD card when the camera or HomeBase Mini is powered on.

5. Decorate the Camera with Stickers (Optional)

- Choose from
 - ① Patterned waterproof stickers
 - ② White stickers for your own designs
- When applying the sticker, ensure the microphone and LED indicator remain uncovered.

Mount the Camera


Disconnect the camera from the power outlet before mounting.

Option 1: On the Table or Shelf

1. Choose a Location

Recommended Location:

- Height of less than 0.8 m (2.6 ft)
- 0.6 m (2 ft) field of view
- Strong Wi-Fi signal



2. Place the Camera


Place the camera on the table or shelf.

Option 2: On the Wall or the Top

1. Choose a Location

Recommended Location:


- Height of less than 2 m (7 ft)
- 7 m (23 ft) field of view
- Strong Wi-Fi signal



2. Install the Mounting Bracket

This bracket can be installed either way —just attach the side with 2 holes to the wall or the top.

Do not install the bracket in any manner other than as described in the manual. Improper installation may result in the camera falling.




Wall Mounting

Top Mounting



3. Mount the Camera

The opening on the back of the camera is a drainage vent which is safe by design. Do not insert objects into it.


- ① Connect the USB-C Cable to the USB-C Port




- ② Attach the Camera to the Mounting Bracket



③ Slide to Lock the Camera




④ Fix the Cable




After Mounting


1. Connect to Power



2. Adjust the Camera Field of View



① Remove Protective Film



② Rotate to Get the Optimal Angle



There is a risk of the camera freezing and failing to rotate under extreme rain or snow conditions.

3. Adjust the Antenna

